

SECTION A-A

GRIP SCREW LOCATION



DETAIL #30

FRAME TANG



RIGHT SIDE
MAG. CATCH DETAIL



SECTION B-B

DETAIL #30

FRONT END VIEW
FRAME
#30





FRONT END VIEW



DETAIL DIMENSIONS



DETAIL #30

SECTION A–A
MAG. OPENING



SECTION C–C
TRIGGER SECTION



SAFTEY CATCH
SLOT DETAIL



SLIDE STOP
SLOT DTEAIL

DETAIL #30

SECTION D–D



DETAIL #30

SECTION A-A
BACK END VIEW